

S100 QE-12E-0253

June 12, 2001

# Service Manual (Simplified Manual)

# m. Ciyooka

## **DETAILS**

Description	Part Number	Remarks
S100	QY8-1378-000	As product exchange servicing
Simplified Manual		applies, only required data is
		included.

# S100/S100SP

# **Simplified Manual**

QY8-1378-000

1	<b>Product / Option / Consumable list</b>
2	Specifications
3	Error code list
4	Service mode
	(Test print, EEPROM reset)
5	External view / Parts list
6	H/W troubleshooting flowchart
7	Special Service Information
ttached	Service Test Print

BPQA-21 Rev 01 2001.6.12

# 1. Product / Option / Consumable lists

## 1.1 Products

Product Name	Product Code	Sales territory	Remarks
Canon Bubble Jet Printer	6863A001AA	USA	
S100	6863A002AA	CANADA	
	6863A003AA	LATIN(LV)	
	6863A004AA	LATIN(HV)	
	6863A005AA	ARG	
	6863A006AA	EUROPE	
	6863A007AA	GERMAN	
	6863A008AA	FRANCE	
	6863A009AA	U.K.	
Canon Bubble Jet Printer	6863A010AA	JAPAN	
BJ S100			
Canon Bubble Jet Printer	6863A014AA	AUSTRALIA	
S100SP	6863A012AA	ASIA(HV)	
	6863A013AA	CHN	
	6863A015AA	HK	
	6863A016AA	KRN	
	6863A017AA	Malaysia	
	6863A011AA	TWN	

## 1.2 Options

None

## 1.3 Consumables

Product Name	Product Code	Remarks
Canon BJ Cartridge	F45-0561	BJ Cartridge (BK)
BC-20		
Canon Color BJ Cartridge	F45-1301	BJ Cartridge (Regular Color)
BC-21e		
Canon Ink Cartridge	F47-0731	Ink tank for BC-21e (BK)
BCI-21 Black		
Canon Ink Cartridge	F47-0741	Ink Tank for BC-21e (Color)
BCI-21 Color		

\*BC-22e / IS-22: Not supported

# 2. Specifications

2.1 Specifications (Note) Differences from the base-model BJC-2100/2100SP are in RED

	tions (Note) L	DeskTop serial color bubble jet printer		
Paper feeding method		Auto Sheet Feeding		
Resolution	ig metilou	720 dpi X 360 dpi		
Print Speed		720 upi A 300 upi		
-		1.5nnm (Color throughput netters)		
	HQ Color Mono.	1.5ppm (Color throughput pattern) 4ppm (Monochrome throughput pattern)		
-				
	HS Color	2ppm (Color throughput pattern)  (Manachroma throughput pattern)		
Drint Directi	Mono.	5ppm (Monochrome throughput pattern)		
Print Direction	ווע	Automatically bidirectional		
		( Printing direction automatically changes according to		
Drint width		print data/ print mode/ installed cartridged type. )		
Print width		203.2mm (8inch)		
Interface	posity of object food ==	USB only		
	pacity of sheet feeder	May Emm stock (Approx E0 shoots with 75 alms)		
	Plain paper	Max. 5mm stack (Approx. 50 sheets with 75g/m²)		
	LGL size	Max. 10 sheets		
	Postcards	Max. 20 sheets		
	Envelopes	Max. 5 sheets		
	Transparencies	Max. 20 sheets		
	Back Print Film	May 4 sheet		
	Glossy photo paper	Max. 1 sheet		
	Glossy film	Max. 1 sheet		
	Fabric	May 4 sheet		
	T-shirt transfer	Max. 1 sheet		
	Banner paper	Max. 1 sheet		
Detection fu	i	V		
	Paper out	Yes		
	Paper width	No		
	Waste ink amount	Yes		
	Presence of BJ cartridge			
	Distinction of cartridge	Yes		
	Ink out	No Voc		
Naisa	BJ/scanner cartridge	Yes		
Noise	tal va autina na t	45 dB (Sound pressure level ISO9296)		
	tal requirement	Tomp 5 to 25 dog C (41 to 05 dog C)		
	During operation	Temp. 5 to 35 deg. C (41 to 95 deg. F)		
	Non aparation	Humidity 10% to 90%RH (no condensation)		
	Non operation	Temp. 0 to 35 deg. C (32 to 95 deg. F)		
Dougos ours	N/	Humidity 5% to 90%RH (no condensation)		
Power suppl		(AC100)//120)/ F0/60Hz (L)// Janan HSA Canada		
	input voitage/Frequenc	y AC100V/120V 50/60Hz (LV) Japan, USA, Canada AC220/240V 50Hz (HV) Europe, Asia		
	Dower concurrentias	(		
	Power consumption	18W		
Stand-by status External dimension		2W		
_		070(M) \		
W paper tray/support		370(W) X 473(D) X 241(H)		
Weight	ofoty otondordo	2.4kg (W/O BJ cartridge and option)		
	afety standards	EGG IG OF Mark TANK FAG O TISK VOOL		
	Printer	FCC,IC,CE Mark,TWN-EMC,C-Tick,VCCI		
Safety		UL,CUL,CB Report,GS,CE Mark,FIMKO,DENTORI,AS,PSB,CCIB,KRN-DENTORI		

#### 2.2 Product life

Whichever of the following comes first

<sup>-5</sup> years

<sup>-</sup>Color printing 3000 pages

<sup>-</sup>Black printing 10000 pages

## 3. Error Code List

Errors will be displayed on the host computer monitor.

The host computer should be set to ECP or Nibble mode. Use the BJ Status Monitor in Windows.

Error Code	Error indication	Error condition	
1000	Printer is out of paper.	Push RESET botton to paper feed.	
1200	Front cover is open.	Close front cover.	
1300	Paper jam	Remove jammed paper.	
1400	BJ cartridge is not installed.	Install BJ cartridge and close front cover.	
1440	Incorrect cartridge is installed.	Install correct BJ cartridge and close front cover.	
5000	Home position error	H/W fail Replace printer.	
5100	Carriage control error	H/W fail Replace printer.	
5200	Head temperature error	H/W fail Replace printer.	
5400	Printer temperature error	H/W fail Replace printer.	
5600	No cartridge while printing	H/W fail Replace printer.	
5B00	Waste ink full	H/W fail Replace printer.	
5C00	Purging operation error	H/W fail Replace printer.	
6100	ROM error	H/W fail Replace printer.	
6300	RAM error	H/W fail Replace printer.	
6800	EEPROM error	H/W fail Replace printer.	

#### 4. Service Mode

Function		on	Procedure	Remarks	
Clean	ing th	ne BJ cartridge	Press and hold the RESET botton for 2 seconds or more (while the AC cord is plugged in)	Cleaning time :Approx.20seconds.)	
Test p	orint 1)	Nozzle pattern	Double click the RESET button. (while the AC cord is plugged in)	Print nozzle check pattern BC-20/21e	
	2)	Service test print Control ROM Version Page throughput Waste ink Amount Destination setting	See *1 service test print'	Needs BC-20 Print sample : See *3	
EEPROM Reset (Reset waste ink amount)			See *2 EEPROM reset / Destination setting		
Destination setting (Japan/SP/Other)		9	See *2 EEPROM reset / Destination setting		

#### \*1 Service test print

- -1 Without the cartridge installed, connect the AC power while holding down the RESET button.
- -2 Release the RESET button, press it down again within 5 seconds and release.
- -3 Open the front cover, install the BC-20 (black BJ cartridge) and set A4-sized paper.
- -4 Double click the RESET button.
- -5 Close the front cover.
- -6 The printer starts service test printing.

#### \*2 EEPROM reset / Destination setting

- -1 Without the cartridge installed, connect the AC power while holding down the RESET button.
- -2 Release the RESET button, press it down again within 5 seconds and release.
- -3 Hold down the RESET button for 2 seconds or more and release.
- -4 < EEPROM Reset >

#### < Destination setting >


Hold down the RESET button for 2 secs or more and release. -Japan Press the RESET button once. -SP Press the RESET button 3 times

-SP Press the RESET button 3 times
-Others Press the RESET button twice


After the button is pressed, the carriage will move same number of times as the RESET button is pressed.

#### \*3 Print sample of 'Service test print'

You can check the EEPROM settings by conducting a 'Service test print'.



# 5. External View / Parts List




**Parts List** 

Key	Part Number	Rank	Q'ty	Description	Remarks
Α	Q10-1003-710	N	1	WHOLE UNIT, W/O POWER SUPPLY UNIT	
В	QH3-3442-000		1	AC Adapter 100/120V 50/60HZ	LV(USA,CANADA,JAPAN)
	QH3-3445-000		1	AC Adapter 220/240V 50/60HZ	HV(Europe)
	QH3-3448-000		1	AC Adapter 220/240V, CHN/ASIA/AUS	HV(CHN,ASIA,AUS)
	QH3-3452-000		1	AC Adapter 220/240V, KRN	HV(KRN)
	QH3-3450-000		1	AC Adapter 100/120V, TWN	LV(TWN)

## 6. H/W Troubleshooting Flowchart

(Confirmation of printer operation when refurbishing)



<Note for normal printer refurbishment>

At the final step of refurbishment, be sure to set the purge reminder flag in accordance with

4. Service Mode <EEPROM RESET>. The purge reminder flag is set by initializing the EEPROM. Unplug the power cord immediately, and do not print afterwards.


(Purge Reminder flag: Factory set so that purging operation will be performed twice when user initially installs the print head.)

## 7. Service Information

#### 7.1 Replacement using whole unit

Whole Unit (WHOLE UNIT, W/O POWER SUPPLY UNIT: Q10-1003-710)

- 1 Remove the AC adapter from the printer returned by the user.
- 2 Install the removed AC adapter in the replacement unit.
- 3 Affix the product name label to the replacement unit. (The label has been packaged with the replacement unit)
- 4 Set destination. (See "4.Service Mode" for detail)
  - < Composition of WHOLE UNIT, W/O POWER SUPPLY UNIT>



Enclosed
Printer unit (No product name label / No AC adapter)
Paper pick-up tray
Paper output tray
Product name labels
Packing material

#### 7.2 Differences from the BJC-2100/2100SP

	BJC-2100/2100SP	S100
I/F	Parallel I/F and USB	USB only
External Color	Two-tone color	Two-tone color
	Lower case/Paper output tray: Gray	Access Cover/Paper output tray: Persona Blue
	Other: Current color	Others: Canon Neutral 7.0
Paper output tray	2 part construction	1 part construction
	Can be folded	Cannot be folded
Cartridge	BC-20/BC-21e/BC-22e/IS-22	BC-20/BC-21e
		(BC-22e/IS-22: Not supported)

## **Attached Sample (Service Test Print)**

Check item 1 (Non ejection of ink) : Total area of the sample below

